

Installation

1. Determine the required ceiling level and mark the line on wall for perimeter of the ceiling. Then fix wall angle on this line level.
2. Fix soffit cleat at spacing 1.20 m x 1.20 m by expansion bolt 6 mm. Then prepare T-Bar hanger, engage on end of hanging wire into soffit cleat.
3. Use Main T as primary channel. Hang by insert the other end of hanging wire into Main T. By this stage Main T should be interval at 1.20 m. spacing.
4. Install the Cross T 1.20 m perpendicularly to Main T at spacing 0.60 m. (for 60 x 120 cm. grid system). However if 60 cm x 60 cm grid system required, just insert Cross T 0.60 m into the slot at the middle of Cross T 1.20 m

